



# TRAIL-GEAR<sup>®</sup>

## Off Road Supply

Differential Stud Eliminator Kit

140056-1-KIT



### Kit Contents:

Allen Head Bolts, M8-1.25x40	10.0
Washer, Flat M8	10.0
Washers, Lock M8	10.0
Nut, Hex, M8-1.25 CL10	10.0
Ultra Grey <sup>®</sup> Silicon	1.0

### Suggested Tools:

Blue LocTite<sup>®</sup> (optional)  
13mm Socket  
5mm Allen Wrench

If you have any questions during the installation of your kit, please call us for assistance at 559-252-4950

## Step 1

### Preparing the Axle:

Start by removing the axles from the housing. Remove the 10 nuts holding the differential in place. Slide the differential out of the housing. Remove all 10 studs from the housing. Clean off all remains of the previous differential gasket. For ease of installation, we recommend chasing all threads before continuing.


## Step 2



### Install Studs:

Place one flat washer onto each new bolt. Thread each bolt in from the inside of the housing. Blue LocTite<sup>®</sup> can be used if desired. Tighten studs with a 5mm allen wrench.

**Note:** If you are using a Rock Assault<sup>™</sup> Housing, see Step 3.



### Step 3 (Optional)

If you are using a Rock Assault housing, you will need to use the studs that came with the Rock Assault housing for the two lower studs.

## Step 4



### **Install Differential:**

Once all 10 Studs have been installed, spread out a thin layer of Ultra Grey® silicon over the face of the 3rd member. Slide the 3rd member back into position on the housing. Place a lock washer and nut on each stud. Tighten nuts in a star pattern.

Reinstall axles into the housing and fill the differential with gear lube. Recheck nuts after the first trail run.



These instructions are designed as a general installation guide. Installation of many Trail-Gear Products require specialized skills such as metal fabrication, welding and mechanical trouble shooting. If you have any questions or are unsure about how to proceed, please contact our shop at 559-252-4950 or seek help from a competent fabricator. Using fabrication tools such as welders, torches and grinders can cause serious bodily harm and death. Please operate equipment carefully and observe proper safety procedures.

Rock crawling and off-road driving are inherently dangerous activities. Some modifications will adversely affect the on-road handling characteristics of your vehicle. All products sold by Trail-Gear Inc are sold for off road use only. Any other use or application is the responsibility of the purchaser and/or user. Some modifications and installation of certain aftermarket parts may under certain circumstances void your original dealer warranty. Modification of your vehicle may create dangerous conditions, which could cause roll-overs resulting in serious bodily injury or death. Buyers and users of these products hereby expressly assume all risks associated with any such modifications and use.

Revised 8/18/2021

Copyright 2010 Trail-Gear Inc.

[www.Trail-Gear.com](http://www.Trail-Gear.com)

