KC® MOUNTS #73500 - TOYOTA 4RUNNER 2010-2020

INSTALLATION INSTRUCTIONS

IMPORTANT:

Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



PARTS INCLUDED: (Lights are sold separately)

QTY 2 - Ditch Mounts

TOOLS NEEDED FOR INSTALLATION:

Wrench Set

STEP BY STEP INSTALLATION INSTRUCTIONS

Only install one side at a time to ensure hood alignment is maintained.

- 1. Only install one side at a time to keep the hood aligned.
 - **DO NOT REMOVE BOTH BOLTS**
- 2. Install the Ditch Bracket on only the top bolt hole and tighten top bolt until snug. Pro Tip: Give yourself enough room to remove the next bolt.
- 3. Remove bottom bolt on hood hinge and rotate the Ditch Mount Bracket until the bottom bolt lines up.
- 4. Reinstall bottom bolt and tighten both bolts to secure both hood and Ditch Bracket. If your hood slips out of place, simply push down on the hood to re-align. Use caution when tightening bolts to avoid cracking powder coat which can lead to rust.