




## **04-08 F150 REAR SUPERBUMP INSTALLATION INSTRUCTIONS FOR WOR-308439**

	<b>NOTICE</b> Read instructions completely before installing this product. Refer back to the instructions frequently during installation.		<b>CAUTION</b> Flying Object Hazard. Fluid Splash Hazard. Wear safety glasses at all times when working on vehicle.
 <b>WARNING:</b> Cancer and Reproductive Harm - <a href="http://www.P65Warnings.ca.gov">www.P65Warnings.ca.gov</a>			



1. Using a 13mm socket, remove the stock bump stop mounting bolt and stock bump stock.



**WOR-308465**

2. Insert the provided mounting bolt into the Superbump.



3. Using the provided 8mm Allen wrench install the Superbump and mounting bolt into the stock bump stop location.

