




## **CHEVY COLORADO SUPERBUMP INSTALLATION INSTRUCTIONS**

	<b>NOTICE</b> Read instructions completely before installing this product. Refer back to the instructions frequently during installation.		<b>CAUTION</b> Flying Object Hazard. Fluid Splash Hazard. Wear safety glasses at all times when working on vehicle.
---	--	--	--

**WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

### **FRONT SUPERBUMP INSTALL KIT: WOR-308486**

**1.** Raise and support front end to have suspension in full droop and remove the wheel. This will give you the best access to the bump stop bracket.



**2.** Remove the factory bump stop. This can be done using a flathead screwdriver.



**WOR-308506-INS**

**3.** Cut or grind off the cup that housed the factory bump stop. Make the surface flush with the bottom plate as shown above.



**4.** Using the access hole on the opposite side of the bracket, install the new Superbump bump stop with the provided special hex wrench and a 14mm wrench. Repeat steps 1-4 on the opposite side of the truck.



## **REAR SUPERBUMP INSTALL KIT: WOR-306951**

1. Support vehicle and axle at the same time in preparation to loosen U-bolts. Remove wheel as shown for easy access to install.



2. Loosen U-bolts enough to remove the factory bump stop.



**3.** Replace with the new Superbump bump stop centered above the alignment pin. Align the U-bolts vertically as shown and tighten to factory specifications. Repeat steps 2-3 on the opposite side.

